



NOTES:

1. ANODE BAGS SHALL BE INSTALLED AT ALL BOLT REPLACEMENT VALVES (ONE PER LOCATION), AT ALL LOCATIONS AS INDICATED PER CITY DETAIL PLATES OR AS DIRECTED BY THE CITY ENGINEER.
2. DO NOT LAY THE ANODE BAG IN CONTACT WITH THE PIPE OR WITH ANY ABANDONED OR FOREIGN SYSTEM.
3. AFTER THE ANODE HAS BEEN LAID IN THE TRENCH, BACKFILL WITH WELL COMPACTED MOIST SOIL. ONCE COMPACTED, TO ENSURE THE SOIL IS MOIST, POUR A FIVE-GALLON (5) BUCKET OF WATER TO THE SOIL DIRECTLY AROUND THE SACRIFICIAL ANODE.
4. THE ANODE SHALL BE INSTALLED TO PROVIDE A MINIMUM OF 5' OF HORIZONTAL SEPARATION AND 16" BELOW THE WATERMAIN.



SACRIFICIAL ANODE BAG INSTALLATION

REVISED: 2-24

ENGINEERING DEPARTMENT

PLATE NO.:

1013